



## REPLACING AN ULTRAVIOLET LAMP

### WHAT YOU NEED :

- UV bulb
- Allen Key

### INSTRUCTIONS

01. Isolate power by removing the plug from the socket
02. Remove the baskets and basket holder
03. Lift the lid of the polisher and leave it open
04. Take the allen key provided and undo the two side screws as below;



05. The front will now pivot down like this;



06. The pointer shows the ultraviolet lamp, simply place your thumb and forefinger over the lamp and twist it anti-clockwise, then gently pull the bulb and it should slide out easily (do not use force!).
07. Unwrap the new bulb and do the reverse of number 06. above. Twist clockwise to locate new bulb.
08. Lift up front until flush with sides, refit the two screws with the allen key, close lid and fit basket holder and baskets
09. Plug in the machine and switch on to test. Make sure that a blue light emits from the cutlery outlet chute.
10. Please dispose of the old lamp safely and call us if you have any problems with the above.