



## CHANGING YOUR GRAIN

### WHAT YOU NEED :

- Polishing Grain
- Vacuum
- Damp cloth

### INSTRUCTIONS :

01. Isolate power by removing the plug from the socket
02. Lift lid of cutlery polisher
03. Unscrew and remove the fastening knob and remove the basin lid
04. Vacuum out all of the grain currently in the polisher
05. Wipe over the internal surfaces to remove any dust
06. Empty contents of a new bag of grain into the machine
07. Assemble the basin lid and close the machine lid

### HOW OFTEN YOU SHOULD CHANGE YOUR GRAIN :

We recommend changing your grain monthly, simply make a note of the date and change it on that date every month. If you are not a busy site, you can change it up to 8 weeks. DO NOT leave it longer than 8 weeks.

Change your grain if...

- You have been using the same grain for 8 weeks
- Your cutlery is coming out slower due to not enough grain in the tank
- Your grain colour has changed from beige to a darker brown colour
- Results are not as good as previously
- There has been a spillage of anything other than water into the polisher

8 weeks maximum!

