



The Glass
Polisher
Company Ltd

CUTTLERS
GP360 Glass Polisher

Contact us for
replacement brushes or
to book a service.
01474 873 892



4 EASY STEPS TO PERFECT GLASSES

STEP 1 | Switch on and allow 10 minutes for the brushes to warm up

STEP 2 | **Make sure that the glasses to be polished are clean and still damp before polishing.**

STEP 3 | Hold the glass by the stem and gently lower the glass onto the centre brush, the centre brush polishes the inside and the 4 outer brushes polish the outside.

STEP 4 | Hand wash brushes at the end of the day with mild detergent and hot water. Leave upright overnight and use polisher to finish drying process if still damp the next day. Wipe over the machine with a damp cloth to remove any dust.

Please see reverse for problems, solutions and further cleaning instructions



The Glass
Polisher
Company Ltd

COMMON PROBLEMS & SOLUTIONS

PROBLEM | Smearly glasses after polishing
SOLUTION | The glass washed is not cleaning correctly or the brushes need cleaning.

PROBLEM | Lipstick on the glass
SOLUTION | Lipstick needs to be removed during cleaning process.

PROBLEM | Glasses are still wet after polishing
SOLUTION | Allow the brushes to dry completely by leaving on for 15 minutes.

CLEANING & MAINTENANCE

DAILY | For perfect results, hand wash brushes everyday and wipe over the polisher with a damp cloth to remove any dust/residue build up.

WEEKLY | Weekly or as required, place all 5 brushes into a pillow case and wash in the washing machine at <60 degrees, stand upright and leave to dry overnight.

MONTHLY | Clean the filter under the machine once per month